

## SETTING FOR OVEN CLEANING

(applicable to models having the self clean option)




This section is applicable only to appliances featuring oven self-cleaning.



### WARNING:


Remove racks from the oven. Racks will become dull and blue-gray if left in the oven during a self-clean cycle.

Oven cleaning cycle time should not have to exceed 4 hours, in order to minimize energy consumption. Three hours is sufficient in most cases.

### To program a cleaning cycle:

**1- Turn selector knob and temperature control knob to the CLEAN  and then press COOK TIME  ; the cook time  indicator is on.**



**2- Press INCREASE  until desired clean time is displayed. Press DECREASE  if you over-shoot the desired clean time.**


**3- Press START  to start the oven clean cycle. The oven signal light is on.**




As soon as the controls are set, the motor driven door lock will begin to close and the cleaning cycle will begin. It takes about 15 seconds for the door to completely lock.

The door can be opened before the oven temperature reaches 290°C (560°F).

The **CLEAN** signal light  goes on.

**4- When the clean cycle is completed, three successive beeps sound; cook time  indicator is off. Turn oven selector and temperature control knobs to OFF  . The oven signal light is now off.**

The oven must **COOL FOR ABOUT ONE HOUR** or until the interior temperature has dropped below 290°C (560°F). **Only then can the door be opened.** The **CLEAN** signal light  goes out.

The clean cycle can be cancelled at any time by turning the selector and temperature control knobs to **OFF  .** Similar result can be achieved by **pressing COOK TIME  , followed by pressing CANCEL  .**

The drip trays under the elements can be cleaned during the self-cleaning process. Only the drip trays made of porcelain enamel may be cleaned; trays made of aluminum or chrome plated steel should be cleaned in the sink. Place the drip trays on the racks making sure they don't touch each other. We are aware that the racks may discolor if left in the oven during self-cleaning (see first paragraph this page), however in order to clean the drip trays, the racks must be left in place.

If you intend to clean the broiler pan in the oven, wipe off excess grease and spillage from it, then place it upside down on an oven shelf.

Note: This insert is taken from the Owner's Manual